

DQ3722M is 3-phase stepper motor driver based on advanced DSP control. It is new fully digital driver configured by DSP control chip and unique circuit. The driving voltage is AC110-220V, adapting to all models of 3-phase hybrid stepper motor whose current is below 7.0A and with 57-130mm outer diameter. The internal driver circuit is similar to that of servo control, which makes the motor run smoothly, almost no vibration and noise. The max positioning accuracy can be up to 60,000 steps/R. It is widely applied in large/medium NC equipment with high resolution like engraving machines, medium CNC machine, packaging machinery and etc.

Features

- High performance and competitive price
- 16-channel equal angle torque micro steps, max resolution 60,000 steps/R
- Max response frequency up to 200Kpps
- Coil current will be automatically reduced to 1/2 of pre-set current when stepper pulse stops over 100ms.
- Optical isolating signals I/O
- Driving current can be adjusted from 1.2A/phase to 7.0A/phase through the 16 channels.
- Single power supply (Voltage range: AC110-220V)
- **Phase memory function (Note: The driver can memorize the motor phase automatically when the input stops over 3 seconds. And also it can recover the phase automatically when it is re-powered or MF signals changes from low level to high level.)**

Current Setting

The working current of the driver is set by DIP-1 terminal. For more details, please refer to the following sheet.

| Running current (A) | 1.2 | 1.5 | 2.0 | 2.3 | 2.5 | 3.0 | 3.2 | 3.6 | 4.0 | 4.5 | 5.0 | 5.3 | 5.8 | 6.2 | 6.5 | 7.0 |
|---------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| D1 | OFF | ON |
| D2 | OFF | OFF | OFF | OFF | ON | ON | ON | ON | OFF | OFF | OFF | OFF | ON | ON | ON | ON |
| D3 | OFF | OFF | ON | ON |
| D4 | OFF | ON |

Micro Steps Setting

The micro steps of the driver are set by DIP-2 terminal with the following 16 channels. They are set separately by the first 4 of the 6 DIP-switch. (The other 2 are for function setting).

Details are as below. Micro steps (pulse/R)

| | 400 | 500 | 600 | 800 | 1000 | 1200 | 2000 | 3000 | 4000 | 5000 | 6000 | 10000 | 12000 | 20000 | 30000 | 60000 |
|----|---|-----|-----|-----|------|------|------|------|------|------|------|-------|-------|-------|-------|-------|
| D1 | ON | ON | ON | ON | ON | ON | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| D2 | ON | ON | ON | ON | OFF | OFF | OFF | OFF | ON | ON | ON | ON | OFF | OFF | OFF | OFF |
| D3 | ON | ON | OFF | OFF | ON | ON | OFF | OFF | ON | ON | OFF | OFF | ON | ON | OFF | OFF |
| D4 | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF | ON | OFF |
| D5 | ON, double pulse: PU is CW stepper pulse signal, DR is CCW stepper pulse signal. | | | | | | | | | | | | | | | |
| | OFF, single pulse: PU is stepper pulse signal, DR is direction pulse signal. | | | | | | | | | | | | | | | |
| D6 | Self-test switch (OFF is to receive external signal, ON is running at speed of 30r/min) | | | | | | | | | | | | | | | |

I/O Signals

All input signals are optically isolated. To guarantee the reliable running of the built-in high-speed optocoupler, the driving current to control the signal is required to be 15mA at least. And the driver has been set in the optocoupler resistance. When the input voltage is beyond 5V, please limit the current by connecting R if necessary.

Current-limiting Resistance value:


When controller/actuator signal outputs voltage:

+5V, R1=0, R2=0


+12V: R1=510Ω, R2=820Ω;

+24V: R1=1.2KΩ, R2=1.8KΩ


Common Anode Connection for Signal Input



Common Cathode Connection for Signal Input




Connection for Differential Signal Input




Signal Output

The driver outputs the signals through optocoupler. The max driving current can be 50mA.

RDY Signal Output





Waveform Diagram of Signal Input



!Caution


- The input voltage can not exceed AC220V;
- The input control signal level is 5V. Once it is over 5V, please connect resistance to limit current.
- The input of pulse is valid on the trailing edge.
- The driver will stop working once the temperature exceeds 75 degrees. And the ALM will light. Until the temperature drops to 50 degrees, the driver will restart to work after powered-up. Please install the radiator for over-heat protection.
- If short circuit ALM lights, please check motor leads and eliminate other short faults. And then repower up.
- If no motor ALM lights, please check motor leads and repower up.

Diagram of Driver Wiring & Dimension (Unit: mm)



Lead Pin Function Table

| Port | Pin No. | Sym- bol | Function | Note |
|----------|---------|----------|--------------------------------------|--|
| RS-232 | 1 | RX | To receive data | NC |
| | 2 | TX | To send data | NC |
| | 8 | GND | Ground | NC |
| DB15 | 1 | PU+ | Input stepper pulse signal + | Driving voltage+5V--+24V, but if above +5V, current limit resistance is needed. |
| | 2 | PU- | DP5= OFF, PU: stepper pulse signal | It is valid on the trailing edge. Each time pulse changes from high level to low level, motor rotates one step and inputs resistance 220Ω. Request: Low level 0-0.5V, high level 4-5V. Pulse width>2.5μS |
| | | | DP5=ON, PU: CW stepper pulse signal | |
| | 3 | DR+ | Input direction signal + | Driving voltage+5V--+24V, but if above +5V, current limit resistance is needed. |
| | 4 | DR- | DP5=OFF,DR: direction control signal | To change motor rotating direction and input resistance 220Ω. Request: Low level 0-0.5V, high level 4-5V. Pulse width>2.5μS |
| | | | DP5=ON,DR: CCW stepper pulse signal | |
| | 5 | MF+ | Input motor free signal + | Driving voltage+5V--+24V, but if above +5V, current limit resistance is needed. |
| | 6 | MF- | Motor free signal - | Cut off motor current when it is valid (low level). The driver stops working and in free state. |
| | 7、8 | NC | NC | NC |
| | 9 | ALM+ | ALM signal + | It is valid at low level. The driver outputs ALM signal when it is over current or over heating. |
| | 10 | ALM- | ALM signal - | |
| | 11 | RDY+ | Output ready signal + | It is valid (low level) when driver works normally and ready to receive the signal from controller. |
| 12 | | | | |
| 13、14、15 | NC | NC | NC | |
| Motor / | 1、2 | L、N | Power supply | Power: AC110~220V |
| | 3 | PE | Ground | Ground |

| | | | | |
|------------|---|---|------------------|--|
| Power Port | 4 | U | Motor connection |  |
| | 5 | V | | |
| | 6 | W | | |

Possible Problems & Solutions Table

| Problems | Possible Cause | Solutions |
|------------------------|--|--|
| Motor Stopped | Indicator does not light. | Check power supply |
| | ALM lights. | Check if the driver over-current, over-heat, or lack of motor. |
| | Motor spindle is locked. | Check external control signal. |
| | The indicator works normally, the spindle does not lock the motor. | Check if MF signal is valid. |
| Motor Stalled | The max speed is over-set. | Reduce the speed. |
| | Accelerating time is too short. | Lengthen the accelerating time or increase the constant value of pulse wave filtering. |
| Inaccurate Position | The Micro steps set incorrectly. | Choose correct micro steps. |
| | The motor load is too heavy. | Change the motor or appropriately increase driver running current. |
| Electric Leakage | Not reliably grounded. | Make the driver/motor reliably grounded. |
| Driver/Motor Over-heat | Heavy running current or terrible external heat sinking condition | Appropriately reduce running current or improve the ventilation and heat dissipation. |