


# به نام خدا

## روش نصب نرم افزار (IAR ARM 5.30.NRG)

1-فایل **CRACK** را نصب کنید:




2-فایل **IARID.EXE** را اجرا کرده و **HOST ID** خود را ایجاد کنید:




3-فایل های **IARKG.exe** و **crack.cmd** را در درایو **C:/** کپی کنید:



4-فایل *crack.exe* را *edit* کرده و *host id* اصلی خود را وارد کنید:



5-فایل *crack.exe* را باز کرده تا برای شما یک *Crack.txt* ایجاد گردد. آن را باز کرده و از طریق **CTRL+F** کد **KEY** و **INSTALLER** قطعه مورد نیاز خود را پیدا کنید و از آن در **SETUP** نرم افزار استفاده کنید:



```
"EWARM" version "2.1_WIN", no expiration date, exclusive
```

**\*نکته:** توجه کنید در حین کپی کد **KEY** آن را به طور کامل و از ابتدا تا علامت **#** وارد کنید:

6-فایل **SETUP** را اجرا کنید:



**IAR Embedded Workbench for ARM 5.30**

**Enter User Information**

Enter your name, the name of your company and your IAR Embedded Workbench for ARM 5.30 license number.

Name:

Company:

License#:  Can be found on the CD cover, or via e-mail registration

InstallShield

< Back   Next >   Cancel

**IAR Embedded Workbench for ARM 5.30**

**Enter License Key**

The license key can be either your QuickStart key or your permanent key. If you enter the QuickStart key (found on the CD cover), you have 30 days to try the product out. If you have received the permanent key via email, you paste it into the License Key textbox.

License #:

License Key:

[Read License Key From File](#)

C:

InstallShield

< Back   Next >   Cancel

\* برنامه قابل استفاده برای شما کاربر عزیز می باشد \*

\* جوان الکترونیک \*

[WWW.JAVANELEC.COM](http://WWW.JAVANELEC.COM)

TEL: 66728460 & 66712719

FAX: 66711319