



**MITSUBISHI
ELECTRIC**

Changes for the Better

for a greener tomorrow



iQ Platform Compatible
Programmable Controller Engineering Software
MELSOFT GX Works2



GX Works2

Integrated PLC Engineering Software



© 2017 MITSUBISHI ELECTRIC CORPORATION ALL RIGHTS RESERVED

iQ Platform iQSS

Integrated PLC Engineering Software

Ultimate evolution of PLC engineering software

International Standard IEC 61131-3 compliant

Now an easy-to-use engineering software is no surprise.

In addition to its sophisticated usability, the engineering software GX Works2 deploys


the global mainstream concepts of "grouping" and "structuring"

for fundamental improvement of programming efficiency.

The world-standard engineering style begins with GX Works2.



GX Works2



KS2


Concept

Concept.1

All-in-one package

All capabilities required for PLC engineering including the configuration function of the intelligent function module and simulation function are integrated in a single package.


The all-in-one GX Works2 package supports entire engineering such as system design, programming, debug and maintenance.



Concept.2

Make full use of MELSEC PLC modules


GX Works2 enables you to easily make a full use of high-function and high-performance CPUs and modules.



Concept.3

Inherits customer assets

Your legacy GX Developer programs can be used in GX Works2 without any modification. Also, programs written by GX Works2 to the programmable controller can be read using GX Developer. For example, even if GX Developer is installed in a production site's PC, the data created and read with GX Developer can be used with GX Works2 installed in a development office's PC.



Concept.4

Sophisticated usability

The favorable GX Developer functions have been incorporated to GX Works2 and the usability furthermore improved.

The performance has also been refined thus improving each operation to perform smoothly with a high response. The usability will continue to advance.



Concept.5

International Standard IEC 61131-3 compliant

GX Works2 conforms to the engineering tool international standard IEC 61131-3, and supports structured programming with grouped parts.

Programming languages including SFC, ST and ladders, can be used according to each application.

In addition, several languages including SFC, ST and ladders can be used together in one program.



WORKS2

Program
FunctionBlock



INDEX

Improving design and debug efficiency

- Ladder input..... P.7
- Comment..... P.11
- Parameter setting..... P.13
- Debugging..... P.17

Providing maintenance that meet your needs

- Operation and maintenance..... P.19
- Security..... P.23

Facilitating project management

- Project..... P.25

Promoting program standardization

- Making parts in program..... P.29
- Label programming/Structured programming..... P.33
- Interaction with iQ Works..... P.35

Powerful collaboration and support of FA devices

- Collaboration with FA devices..... P.37

- CC-Link Association..... P.39
- Global support..... P.40
- Specifications/Products..... P.41
- FA Products..... P.43

Ultimate "Easy-to-use" user interface

The engineering software GX Works2 has been developed to allow programming, debugging and maintenance operations, etc., to be carried out easily by anyone with intuitive operations. Its comfortable operation environment further improves design efficiency.

Enhancing program readability with wrapping ladder blockP.10

Distinguish similar devices without bother P.11


Utilizing sample comment saves time to input comments..... P.11

Incorporate a useful setting function from GX Configurator P.13


Program title display guides you..... P.25

Tree view offers easy-to-understand processing flow..... P.26

Easy connection destination setting..... P.27




Offline debugging without PLC.....P.17




Cross Reference interacts with ladder display P.9

Detailed project security managementP.23




Easier-to-use sampling trace ... P.18




Wide, easy-to-read screens enable effective use P.27

Direct writing of operation processing in ladder with inline structured text P.9

Watch windows for quick monitoring of device/label P.17



Easy continuous device search with familiar-to-use operationP.8



Visible System monitor function and PLC diagnosticsP.21

▶ Ladder input

1 Simple key operation makes an easy ladder programming

A ladder is easily modified and edited with convenient key combinations such as [Alt]+[←]/[→] or [Alt]+[↑]/[↓].

Enter Symbol

[-]- MOV D0 K4Y0

OK Exit Help

Edit ladder

[Alt]+[←] ... K4Y0→D0→MOV
[Alt]+[→] ... MOV→D0→K4Y0

Alt + ← / →

Change device number

[Alt]+[↑] ... K4Y0→K4Y1→K4Y2
[Alt]+[↓] ... K4Y2→K4Y1→K4Y0

Alt + ↑ / ↓

Click Undo button.

Undo

Undo up to 30 previous input steps with Undo ((Ctrl)+[Z]).

Ctrl + Z

The device number is automatically incremented when continuously pasting cut & copied ladders.

Continuous Paste

Continuously paste the selected range downward from current cursor position with device no. increments which is included in cut or copied ladder.

Number of Pasting Operations (1 to 99): 3 lines

Copy Source Device	After Increment	Increment Value
105(Q0.0)	>> 105(Q0.1)	1
100	>> 100	1
102	>> 102	1
120(A)	>> 120(A)	1
106(I)	>> 106(I)	1
105(Q0.0)	>> 105(Q0.1)	1
108	>> 108	1
103	>> 103	1

* Setting range for increment value is within the range of -9999 to 9999 (DEC).
* Real constant, devices in nine 17 will not be incremented.
* Paste under Insert Mode.

Execute Cancel

Easy-to-read ladder display

The number of contacts in a single line can be changed to 9, 11, 13, 17 or 21.

Easy to view ladder with no wrapping

2 Edit lines with simple key operation

Lines are edited only with the keyboard keys. There's no need to switch to the conventional line editing mode.

Press **Ctrl** + **→** or **Ctrl** + **↓** to draw a line.

Press **Ctrl** + **Shift** + **→** to draw a line to the coil consecutively.
(Press **Ctrl** + **Shift** + **↓** to draw a vertical line consecutively.)

Edit line

Press **Ctrl** + **→** or **Ctrl** + **↓** where no line is drawn to draw a line.
Press **Ctrl** + **→** or **Ctrl** + **↓** where a line is drawn to delete the line.

3 Easy ladder edit with command/label input support

Ladders are easily edited just by choosing.

The information of arguments are also shown to reduce errors during ladder input.

Explanation of suggested instruction
The details of each instruction can be understood at a glance from explanation of each.

Explanation of argument type
Explanations of arguments are also displayed so that a ladder can be edited without any help.

Auto suggest instructions
Suggestions appear when the first character is input. Easily edit the ladder even when there are too many instructions to remember.

Explanation of label
Suggested labels are displayed. Edit the ladder without remembering all labels.

POINT This function saves time to display and confirm help information during command input. Pressing the [F1] key displays the instruction help screen.

4 Easy continuous device search

By specifying the search option and pressing the Enter key, the user can search for suggestions.

This is particularly useful when a certain device is used many times in the program.

Search for a label is conducted by partially entering it.

Pressing **Ctrl** + **F** searches for the first "Auto" candidate.

Continuous search
By specifying the option and pressing the Enter key, search for the specified device is made continuously.

Pressing Enter key searches for the next "Auto" candidates. (Cursor moves to it.)

POINT Search for devices can also be made in the similar manner by switching the ladder display to the device display.

▶ Ladder input

5 Cross Reference interacts with ladder display

Cross Reference function is used to search for devices/labels used in the project. The docking windows enable to display the Cross Reference window and program editor vertically.

Automatically displays the Cross Reference information of the device at the cursor position.

Several reference sites can be set for the search.

Double-click

Click!

Jump to the step using this device/label.

Device/Label	Device	Instruction	Ladder Symbol	Position	Step	Program
CycleNode	REL01	LD	- -	Step No 24	Auto	
CycleNode	REL01	LD	- -	Step No 29	Auto	
CycleNode	REL01	LD	- -	Step No 88	Auto	
CycleNode	REL01	LD	- -	Step No 117	Auto	
CycleNode	REL01	LD	- -	Step No 175	Auto	
CycleNode	REL01	LD	- -	Step No 419	Auto	
CycleNode	REL01	LD	- -	Step No 424	Auto	

POINT The used locations of devices or labels in the program are confirmed with intuitive operation.


6 Inline ST directly writes operation processing.

Operation processing is written directly in a ladder with Inline ST (structured text). Creation of a multi-line ladder or FB (Function Block) in another program editor is not necessary anymore.


Example of numeric operation
[Using ladder only]



Example of character string processing
[Using ladder only]




[Using Inline ST (structured text)]



ST edit area
The current value can be monitored and changed.

[Using Inline ST (structured text)]




Describe a program in one line using Inline ST.

POINT Troublesome numeric operations and character string processing are described easily.


7 Enhancing program readability with wrapping ladder block

By wrapping a ladder block, a long and hard-to-read ladder program is displayed in a compact form.



8 Easier to view SFC diagram and Zoom


The scale of the window is changed to display the SFC diagram and Zoom. Since the changed scale is retained, the windows are always displayed with the same layout.



► Comment

1 Utilizing sample comment saves time to input comments


Pre-prepared special relays/registers of the CPU as well as the buffer memory/XY signal of the intelligent function module is copied as sample comments in the project comments.



POINT Time for entering device comments are greatly saved by utilizing sample comments.


2 Distinguish similar devices without bother

Set a word device comment for each bit to display the contents of the comment on the ladder.




3 Easily copy and utilize device comments

Device comments are copied by copying the ladder of the ladder editor between projects. When copying a ladder onto another program, the device comments in the ladder are also copied.



4 Utilize device comments created in other languages

Japanese, Chinese (Simplified and Traditional), and Korean comments can be displayed in GX Works2 English Edition. The function comes useful when working with offices abroad.




▶ Parameter setting

1 Incorporate a useful setting function from GX Configurator

The setting function of the intelligent function module is now integrated with GX Works2. The intelligent function module settings are managed in a GX Works2 project.

■ Add new module screen




2 Displays device assignment of CC-Link


A network configuration diagram is created by arranging device images on the CC-Link Configuration window using a mouse. A list of refresh devices assigned to CC-Link modules are displayed.

CSP+*1, which contains partner product information, can be additionally imported.

*1 Refer to the CC-Link Association website (<http://www.cc-link.org>) for information on CSP+.



The equipment configuration diagram is created intuitively using CC-Link Configuration Window.



Drag & drop to add devices to connect. Operations are easy since parameters and link scan time are automatically set.



Start from the toolbar.

CC-Link Device Reference - Master Station Start I/O

Master/Local Start I/O No.: 0060

Host STA	Refresh Device	STA#	Link Device	Explanation
D0			RW0	1st monitor val
D1		1	RW1	2nd monitor va
D2		<=	RW2	Reply code
D3			RW3	Read data
D4			RW0	CH1 digital outf
D5			RW1	CH2 digital outf
D6			RW2	CH3 digital outf
D7			RW3	CH4 digital outf
D8			RW4	CH5 digital outf
D9			RW5	CH6 digital outf
D10		<=	RW6	CH7 digital outf
			RW7	CH8 digital outf
				Error code

Display the device assignment list. Programming is made while viewing device assignment.


POINT The device assignment information can be exported to a CSV file and imported into the global label information, making it easy to utilize the information in label programming.

▶ Parameter setting


3 Easy connection via serial/Ethernet

Using the predefined protocol function of GX Works2, connection to a device you want to communicate with is quickly made just by choosing it from the predefined protocol library.

Even if the external devices are not registered in the predefined protocol library, the desired protocol is easily created.



During serial communication, transmitted data, communication signals, and communication statuses can be checked without a line analyzer, making debugging easier.



4 Set and monitor iQSS supporting devices

iQSS

GX Works2*1 enables setting and monitoring of iQSS supporting devices, represented by vision sensors.

*1 GX Works2 with version 1.492N or later.

■ Examples for Ethernet supporting devices

Device list
Devices connected to the Ethernet network are listed.

Configuration diagram
Graphical images of devices connected to the Ethernet network are displayed.


Output window
Status or error information of the selected iQSS supporting device is displayed.

Ethernet supporting devices on the network are automatically detected. Parameters for auto-detected devices can be set.

▶ Debugging

1 Offline debugging without PLC

The simulation function is now integrated with GX Works2. The program operation is easily checked on a personal computer.



Debugging is performed with a PC right after programming without PLC.


Checking operation while actually viewing it allows for design without rework.



POINT Up to four GX Works2 projects on a single pc are available to simulate concurrently.


2 Simulation function helps program debugging

A program is executed in a step-by-step method using the simulation function, finding program errors more easily.



3 Watch windows for quick monitoring of device/label


Arbitrary devices/labels are registered and monitored, allowing required sections to be confirmed quickly.



POINT The current value of the device/label is changed from the watch window.

4 Easier-to-use sampling trace

The device values before and after the designated conditions are established can be sampled and displayed in a timing chart. The trace results are saved in a CSV file allowing the device changes to be saved easily.




POINT

The sampling trace is also used in the simulation function.


5 Easier-to-view positioning trace function

Status of the speed command (axis speed), two-axis interpolation, and simultaneous start (two axes) are traced and displayed in a graph.

The value of each axis is visually checked during the online operation of the positioning module.



Trace function screen (Wave trace)




Trace function screen (Location trace)

6 Supporting the real-time monitor of GX LogViewer

The real-time monitor of the MELSEC-L CPU can be used by starting up GX LogViewer*2 from GX Works2*3.

*2 GX LogViewer version 1.40S or later


*3 GX Works2 version 1.521T or later



▶ Operation and maintenance

1 Improved verification function

Verify data of an open project against data of saved project to display the result in an easy-to-view format. The parameters and the programs in the PLC connected to a personal computer also are verified against the data of an open project.



POINT The verification result is saved to a CSV file to facilitate revision of design documents.

2 Prevent edit error by Read and Monitor modes

Erroneous operations in monitoring and searching are eliminated by supporting the Read and Monitor modes similar to GX Developer.

Write mode/monitor (write mode)


Enter Symbol screen opens by pressing Enter key.



In the Write mode/monitor (write mode), online program change during conversion/compile is prevented to accelerate work.

Read mode/monitor mode

Find screen opens by pressing Enter key.



Since programs cannot be edited in the read mode/monitor mode, erroneous editing of the ladder is prevented. The display jumps to the next search candidate each time the Enter key is pressed.



POINT

The same key operation as GX Developer is used to switch modes.

3 Dedicated monitoring for intelligent function module

While watching the ladder program, the buffer memory/XY signal of the intelligent function module is monitored in the docking window. Since the name of each buffer memory address is displayed, so there's no need to refer to the manual to see for what the buffer memory is used.

Show the current values in an easy-to-view format.







Item	Current Value	Device	Data Type
Output Signal(Y)			
Operating condition setting request	OFF	Y29	Bit
User range write request	OFF	Y2A	Bit
Channel change request	OFF	Y2B	Bit
Maximum value/minimum value reset request	OFF	Y2D	Bit
Error clear request	OFF	Y2F	Bit
Buffer Memory Monitor			
Error code	0	U2-G19	Error Code
CH1 A/D conversion completed flag	Unconverted	U2-G10.0	Bit
CH2 A/D conversion completed flag	Unconverted	U2-G10.1	Bit
CH3 A/D conversion completed flag	Unconverted	U2-G10.2	Bit
CH4 A/D conversion completed flag	Unconverted	U2-G10.3	Bit
CH1 Digital output value	0	U2-G11	Word(Signed)
CH2 Digital output value	0	U2-G12	Word(Signed)
CH3 Digital output value	0	U2-G13	Word(Signed)
CH4 Digital output value	0	U2-G14	Word(Signed)

If there are several modules being monitored, press the tab to switch between the modules.

► Operation and maintenance

4 Visible System monitor function and PLC diagnostics

Operation status of the entire programmable controller system is clearly displayed. Each module's diagnosis and detailed information is displayed on the monitor for the entire system allowing the problem point to be confirmed quickly.



POINT The system is diagnosed on a graphical screen which gives a feeling as if you are watching actual system and equipment.

5 Rich print functions

Items to print are specified in details. Also, multiple programs are printed in a single operation.

6 Save and edit labels and parameters with Microsoft® Excel®

Various program data are exported as a CSV format file.

■ Exporting the program data as a CSV format file has the following advantages:

- Data are confirmed even on a personal computer that doesn't have GX Works2.
- Data are saved in the personal computer.
- Data are mailed to a remote location.
- Secondary use of data, such as documentation and graphing, is possible using Microsoft® Excel®.
- Collaborate with other software by handling data in CSV format.

Example of I/O assignment setting CSV file

No.	Name	I/O	Address	Type	Status
1	INT0-0	Intelli-g	0000.0	Input	---
2	INT0-1	Intelli-g	0000.1	Input	---
3	INT0-2	Intelli-g	0000.2	Input	---
4	INT0-3	Intelli-g	0000.3	Input	---

No.	Name	I/O	Address	Type	Status	Switch	Details	Basic
1	INT0-0	Intelli-g	0000.0	Input	---	---	---	---
2	INT0-1	Intelli-g	0000.1	Input	---	---	---	---
3	INT0-2	Intelli-g	0000.2	Input	---	---	---	---
4	INT0-3	Intelli-g	0000.3	Input	---	---	---	---

- Ladder program Write/read
- Label setting Write/read
- Parameter (I/O assignment setting, X/Y assignment confirmation) Write
- Verification results Write
- Sampling trace function Read (CSV file format that can be read with GX LogViewer)
- Watch window device/label list Write/read
- Product information, PLC diagnosis, module error history of system monitor for diagnosis function Write
- Device memory Write/read


► Security

1 Detailed project security management

Project safety is maintained by limiting user access for each program and parameter.


User registration (addition, change, and deletion)

The access level is managed for each user.



Access restriction

Setting security not only restricts an access to projects but also prevents the data created by the user from erroneous modification and/or disclosure to unauthorized users.




POINT When multiple persons take charge in the same project, unauthorized changes to the project data are prevented.

2 Protects the program


Password registration

By setting a password for a program in the programmable controller CPU, the program is protected from unauthorized change and leakage.



Block password setting

By setting a block password, the FBs in a project which contains in-house software expertise are protected from theft and leakage.




3 Prevents unauthorized access

Security Key


By registering the devices that access the CPU, unauthorized access from non-registered devices is prevented.

Avoid unnecessary accesses, and protect your valuable program assets.



Remote password


By setting a remote password, unauthorized access of the programmable controller from Ethernet or a public line is prevented.



► Project

1 Back up and restore a project easily


By registering the project revision history, the project is easily recovered to their original state. Projects with a registered history are compared.



POINT It is unnecessary to save projects under different names for back up.


2 Program title display guides you

In addition to the program name, the program title is displayed, allowing the program contents to be understood at a glance.




3 Tree view offers easy-to-understand processing flow

The statements appended to program processes are displayed on a tree view for easy access to them. The processing flow and structure of the program are easily understood and jump to each process quickly.



4 Handle multiple program parts with FX Series


The PLC program can be created with multiple program parts so the program configuration can be seen and parts can be easily used in other projects.



► Project


5 Fully utilize the wide and easy-to-read screen

The docking windows are hidden to use the screen efficiently.



6 Easy connection destination setting

The settings for frequently connected devices can be saved and reused whenever necessary. This eliminates the need for copying and modifying projects for different connection targets.



7 Customize keyboard key arrangement

The user can customize keyboard shortcuts.
The customized setting can also be saved and exported as a file.

POINT Shortcut keys can be assigned to the menus that have no shortcuts assigned by default.

8 Help information guides you operation method

Displaying Help information with a single keystroke makes it easier to confirm the operation.

POINT Frequently used help screens are bookmarked.


► Making parts in program

1 Make it easy using FB

What is a Function Block (FB)?

Function Block (FB) is a ladder block frequently used in a sequence program and grouped as a part for reuse within the program.



FB improves program development efficiency and reduces programming errors to ensure higher program quality.




Making parts

Example) This count process program turns the output signal (Y12) ON after the input signal (X1) turns on for 12 times.

Program components to be grouped as a part




① Replace input with input label, output with output label and replace the internal devices with internal labels.



② The above ① program is converted and FB is created.

Use FB


The grouped ladder block (FB) can be used repeatedly.



Advantages of using FB


Advantage 1: Easier programming

A sequence program is created just by dragging and dropping FBs. This significantly reduces program development processes.




Advantage 2: Improved readability

Using FBs in a sequence program improves its readability because the program only consists of "boxes" (FBs), inputs, and outputs.




Advantage 3: Reusability

By grouping frequently used program components as parts, they are reused as many times as required. You are no longer required to copy an existing program and then modify devices.



Advantage 4: Higher quality

By grouping frequently used program components as parts (FBs) and reusing them, program quality will be uniform and independent from the skill levels of the developers.



Advantage 5: Theft prevention

By grouping important sequence program components involving technology expertise as a part (FB) and protecting it with a password, information leak is prevented.



► Making parts in program

2 Useful FB libraries supplied by vendors


What is FB library?

An FB library is a collection of FB parts which is used in simple projects of GX Works2.

By using these FBs, settings and operation of the MELSEC-Q/L modules as well as partner products are configured.

In addition to the custom-made FBs, useful FB libraries supplied by our partners are available. FBs are also offered for iQSS partner products.

The MELSOFT Library has more than 1500 FBs from thirteen companies, and is scheduled to continue expanding.



When how to use an FB is not certain, right-click it on the FB Selection Window to display the help information.

The image shows two screenshots from the GX Works2 software. The left screenshot displays the 'FB Selection' window with a list of function blocks. A red box highlights the 'Calculate Check Code' block, and a right-click context menu is open over it, with the 'Data Help' option highlighted. A callout box with an arrow points from this menu to the right screenshot. The right screenshot shows the help information for the 'Calculate Check Code' function block, including its description, symbols, applicable hardware, and programming details.

When you are not sure about how to use FB, just right-click it for help!

Item	Description																																
Function overview	Calculates the Ascii parity value and addition value (check), which are used to check for errors in communication, etc.																																
Symbol	<table border="1"> <thead> <tr> <th colspan="4">M-CPU Data_Calculator</th> </tr> </thead> <tbody> <tr> <td>Execution command</td> <td>FB_CK</td> <td>FB_CK1</td> <td>Execution status</td> </tr> <tr> <td>Completion mode</td> <td>1: Done/Mode</td> <td>FB_CK</td> <td>Completed without error</td> </tr> <tr> <td>Start value No.</td> <td>1: Check Data</td> <td>FB_CK0001</td> <td>Start flag</td> </tr> <tr> <td>No. of steps</td> <td>1: Run Data</td> <td>FB_CK0001</td> <td>Done code</td> </tr> <tr> <td></td> <td></td> <td>FB_CK0001</td> <td>Reset/Run</td> </tr> <tr> <td></td> <td></td> <td>FB_CK0001</td> <td>Reset/Run</td> </tr> <tr> <td></td> <td></td> <td>FB_CK0001</td> <td>Reset/Run</td> </tr> </tbody> </table>	M-CPU Data_Calculator				Execution command	FB_CK	FB_CK1	Execution status	Completion mode	1: Done/Mode	FB_CK	Completed without error	Start value No.	1: Check Data	FB_CK0001	Start flag	No. of steps	1: Run Data	FB_CK0001	Done code			FB_CK0001	Reset/Run			FB_CK0001	Reset/Run			FB_CK0001	Reset/Run
M-CPU Data_Calculator																																	
Execution command	FB_CK	FB_CK1	Execution status																														
Completion mode	1: Done/Mode	FB_CK	Completed without error																														
Start value No.	1: Check Data	FB_CK0001	Start flag																														
No. of steps	1: Run Data	FB_CK0001	Done code																														
		FB_CK0001	Reset/Run																														
		FB_CK0001	Reset/Run																														
		FB_CK0001	Reset/Run																														
Applicable hardware and software	<p>Prerequisite details</p> <table border="1"> <tbody> <tr> <td>Q series</td> <td>High performance model</td> </tr> <tr> <td></td> <td>Universal model</td> </tr> <tr> <td>L series</td> <td>LCPU</td> </tr> </tbody> </table> <p>*Not applicable for QCPU-VR models</p> <p>Compatible software: GX Works2 Version 1.31H or later</p>	Q series	High performance model		Universal model	L series	LCPU																										
Q series	High performance model																																
	Universal model																																
L series	LCPU																																
Programming language	Ladder																																
Number of steps (maximum value)	For high performance model CPU: 256 *The value is the number of steps in the ladder program, and is therefore stated as a reference value. For details, refer to the GX Works2 Version 1 Operation Manual (Help) Project.																																

► Label programming/Structured programming


1 Structured programming

From a roll of ladder program to structured programming

By using a Structured project, a large and complicated program is structured and divided into parts according to the processing details, control details, and functionalities.

A "roll" of ladder program tends to be difficult to view the entire processing. On the contrary, by designing a compact program module for each process in structured programming, coding and debugging will be more efficient and the program quality will be also improved.

It also supports complicated structured programming by allowing for a nesting structure which puts a FB in another FB.



2 International Standard IEC 61131-3 compliant

GX Works2 conforms to the international standard IEC 61131-3.


Graphical language

Ladder language

This graphical language represents a program as a ladder which consists of contact points and coils.

Structured ladder/FBD language

The structured ladder language is a graphical language used according to the design technique of the relay circuit. The structured ladder allows for nesting FBs. The FBD language graphically represents a ladder by connecting functions and/or FBs.




SFC language

A graphical language for comprehensively describing sequence control.

This language pairs a step which describes a process with a transition condition to move to the next step.

The step and transition condition are described in the ladder language.



Text language

ST (structured text) language

The ST language allows for describing control with selection divergence using conditional statements and loops using iteration syntax, similar to high-level languages such as C. This helps creating comprehensive and concise programs.

```


(* Change data *)
IF (X000=TRUE) THEN
  Y001=FALSE;
ELSE
  Y001=TRUE;
ENDIF;

(* Describe control with Selection divergence using conditional statements
and loops using iteration syntax *)
CASE 1 OF
  1: Y001=TRUE; (* Conveyor operation *)
  2: Y001=FALSE; (* Conveyor stop *)
  3: Y001=TRUE; (* Conveyor warning *)
END_CASE;

FOR Counter at 0 to 10
  Y001=TRUE;
END_FOR;
  
```

3 Improve development efficiency using user libraries

With structured projects, frequently-used programs are saved in user library files separately from the project. By importing these user library files into a project, the program is developed efficiently without having to create it from scratch.



4 Label programming

Labels are used to give easily identifiable names such as “Production line start signal” or “Start parts supply” to devices.



POINT Using labels eliminates device assignment upon system changes.

► Interaction with iQ Works


1 Implements a seamless engineering environment

MELSOFT iQ Works is an integrated engineering software product, composing of GX Works3, GX Works2, MT Works2, GT Works3, RT ToolBox2 mini and FR Configurator2. By sharing information such as system designs and programming as the entire control system, the system design and programming efficiency are improved and total cost reduction is achieved.


MELSOFT Navigator

In combination with GX Works3, GX Works2, MT Works2, GT Works3, and RT ToolBox2 mini, this software performs upstream system design and inter-software operation.

It provides such convenient functions as system configuration design, batch setting of parameters, system labeling, and batch reading.



MELSOFT Navigator



■ Workspace management

Multiple project data (programmable controller projects, motion controller projects, GOT projects, and robot controller projects) are managed totally using a workspace.

• System configuration diagram

The overall system is represented graphically with the following configuration diagrams:

- "Network configuration diagram"
- "Module configuration diagrams" showing the placement of modules
- Field network configuration diagrams

("CC IE Field configurations", "CC-Link configurations", "Ethernet configurations", "AnyWireASLINK configurations")

The diagram is easily created by dragging and dropping the modules, and various checks such as power supply capacity check are also performed.

• System label

System labels are set in one place, reducing the number of processes and preventing setting errors.

The set system labels are shared and used with all related projects.


2 Parameter settings for individual tools are no longer required

The information set into the system configuration drawing are reflected in a batch onto the GX Works3, GX Works2, MT Works2 and GT Works 3 projects. *1


There's no need to launch each software and check the integrity.

*1 You are still required to set detailed parameters in each tool.

Parameter setting information in system configuration diagram




Reflected on data of various development tools at once



3 Shares labels and automatically changes all related projects


With MELSOFT Navigator, labels are shared by the PLC, motion controller and GOT.

For example, if a device assignment is changed in the PLC project, the changes are automatically reflected onto the motion controller and GOT projects.



Define labels centrally

Automatically reflects changed information on each project



► Collaboration with FA devices

1 Supporting next-generation high-speed CPUs

GX Works2 now supports the universal model high-speed type QCPU module which has a greatly improved operation and processing speed for basic operations, structural instructions and FB call functions. Use GX Works2 to easily control the next-generation high-speed CPU equipped with advanced functions.

GX Works2 support

- Universal model high-speed type QCPU *1
Q03UDVCP, Q04UDVCP, Q06UDVCP
Q13UDVCP, Q26UDVCP

*1 Supported by GX Works2 version 1.98C and higher.

MELSEC series
QnU

Reduce tact-time with
super fast processing.

Basic operation processing
speed (LD instruction) 1.9 ns




2 Coordination with PX Developer supports process applications


By coordinating with PX Developer*2, sequence and loop control programs can be created for process/redundant CPU.

*2 PX Developer with version 1.36N or later

Process system programming example



MELSEC PROCESS



3 Batch control of various FA devices

Collaboration with various FA devices is now more powerful.
 GX Works2 is used to set and monitor various FA devices on any platform.
 Improve your product site's efficiency by integrating with high-performance and high-function devices.

Standard simple motion module setting tool

Configuration, start up and adjustment, operation and maintenance of the simple motion module are powerfully supported.



System configuration setting



Synchronous control parameter setting



Digital oscilloscope



Energy-saving supported

The power measurement module's parameters are set from the GX Works2 without a manual.
 In addition, the parameter settings and measured value are confirmed easily. (Intelligent function module monitor supported)
 Swift startup using the GX Works2 supports energy conservation of the system.

Supported modules

QE81WH, QE81WH4W, QE83WH4W, QE84WH, QE82LG



Sensor integration iQSS

Parameters for the iQ Sensor Solution (iQSS) compatible partner sensor products are set and monitored, and the sensor's connection state and current values are confirmed with graphically displays, allowing troubles to be handled quickly.

The image shows two screenshots of the GX Works2 interface for iQSS. The left screenshot displays a list of sensors with columns for ID, Name, and Status. A hand icon with a red arrow points to a sensor, with a red callout box saying "Click!". Below the list, a red callout box says "Right-click". The right screenshot shows a detailed view of a sensor's parameters, with a red callout box saying "Parameters are set." Below this, another red callout box says "Status is monitored." The interface includes various graphs and data displays for monitoring sensor performance.

▶ CC-Link Association

CC-Link Partner Association (CLPA) actively promotes the worldwide adoption of CC-Link networks

From promotion to specification development, CLPA actively supports CC-Link

CC-Link Partner Association (CLPA) was established to promote the worldwide adoption of the CC-Link open field network. By conducting promotional activities, such as organizing trade shows and seminars, implementing conformance tests, and providing catalogs, brochures, and website information, CLPA has been successfully increasing the number of CC-Link partner manufacturers and CC-Link compatible products. CLPA takes a major role in the globalization of CC-Link.



Seminar



Trade show



Conformance Testing Lab

The latest CC-Link information is posted on the website.

URL:<http://www.cc-link.org>




6F Ozone Front Bldg. 3-15-58 Ozone,
Kita-ku, Nagoya 462-0825 JAPAN
TEL: +81-52-919-1588 FAX: +81-52-916-8655
E-mail: info@cc-link.org




CC-Link continues to increase its global influence

CC-Link is supported globally by CLPA. With offices throughout the world, support for partner companies can be found locally. Each regional CLPA office undertakes various support and promotional activities to further the influence of the network in that part of the world. For companies looking to increase their presence in Asia, CLPA is well placed to assist these efforts through offices in all major Asian economies.



Extensive global support coverage providing expert help whenever needed

■ Global FA centers



China

1 Shanghai FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD.
No.1386 Hongqiao Road, Mitsubishi Electric Automation Center, Shanghai, China
Tel: +86-21-2322-3030 / Fax: +86-21-2322-3000

2 Beijing FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Beijing Branch
Unit 901, 9F, Office Tower 1, Henderson Centre, 18 Jianguomennei Avenue, Dongcheng District, Beijing, China
Tel: +86-10-6518-8830 / Fax: +86-10-6518-2938

3 Tianjin FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Tianjin Branch
Room 2003 City Tower, No.35, Youyi Road, Hexi District, Tianjin, China
Tel: +86-22-2813-1015 / Fax: +86-22-2813-1017

4 Guangzhou FA Center

MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Guangzhou Branch
Room 1609, North Tower, The Hub Center, No.1068, Xingang East Road, Haizhu District, Guangzhou, China
Tel: +86-20-8923-6730 / Fax: +86-20-8923-6715

Taiwan

5 Taichung FA Center

MITSUBISHI ELECTRIC TAIWAN CO.,LTD.
No.8-1, Industrial 16th Road, Taichung Industrial Park, Taichung City 40768, Taiwan, R.O.C.
Tel: +886-4-2359-0688 / Fax: +886-4-2359-0689

6 Taipei FA Center

SETSUYO ENTERPRISE CO., LTD.
3F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan, R.O.C.
Tel: +886-2-2299-9917 / Fax: +886-2-2299-9963

Korea

7 Korea FA Center

MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD.
7F-9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 157-801, Korea
Tel: +82-2-3660-9605 / Fax: +82-2-3663-0475

Thailand

8 Thailand FA Center

MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD.
12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpan, Khet Yannawa, Bangkok 10120, Thailand
Tel: +66-2682-6522 / Fax: +66-2682-6020

ASEAN

9 ASEAN FA Center

MITSUBISHI ELECTRIC ASIA PTE. LTD.
307, Alexandra Road, Mitsubishi Electric Building, Singapore 159943
Tel: +65-6470-2480 / Fax: +65-6476-7439

Indonesia

10 Indonesia FA Center

PT. MITSUBISHI ELECTRIC INDONESIA Cikarang Office
Jl. Kenari Raya Blok G2-07A Delta Silicon 5, Lippo Cikarang-Bekasi 17550, Indonesia
Tel: +62-21-2961-7797 / Fax: +62-21-2961-7794

Vietnam

11 Hanoi FA Center

MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED Hanoi Branch
6-Floor, Detch Tower, 8 Ton That Thuyet Street, My Dinh 2 Ward, Nam Tu Liem District, Hanoi, Vietnam
Tel: +84-4-3937-8075 / Fax: +84-4-3937-8076

12 Ho Chi Minh FA Center

MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED
Unit 01-04, 10th Floor, Vincom Center, 72 Le Thanh Ton Street, District 1, Ho Chi Minh City, Vietnam
Tel: +84-8-3910-5945 / Fax: +84-8-3910-5947

India

13 India Pune FA Center

MITSUBISHI ELECTRIC INDIA PVT. LTD. Pune Branch
Emerald House, EL-3, J Block, M.I.D.C Bhosari, Pune-411026, Maharashtra, India
Tel: +91-20-2710-2000 / Fax: +91-20-2710-2100

14 India Gurgaon FA Center

MITSUBISHI ELECTRIC INDIA PVT. LTD. Gurgaon Head Office
2nd Floor, Tower A & B, Cyber Greens, DLF Cyber City, DLF Phase-III, Gurgaon-122002 Haryana, India
Tel: +91-124-463-0300 / Fax: +91-124-463-0399

15 India Bangalore FA Center

MITSUBISHI ELECTRIC INDIA PVT. LTD. Bangalore Branch
Prestige Emerald, 6th Floor, Municipal No. 2, Madras Bank Road (Lavelle Road), Bangalore-560001, Karnataka, India
Tel: +91-80-4020-1600 / Fax: +91-80-4020-1699

16 India Chennai FA Center

MITSUBISHI ELECTRIC INDIA PVT. LTD. Chennai Branch
"Citilights Corporate Centre" No.1, Vivekananda Road, Srinivasa Nagar, Chetpet, Chennai-600031, Tamil Nadu, India
Tel: +91-44-4554-8772 / Fax: +91-44-4554-8773

17 India Ahmedabad FA Center

MITSUBISHI ELECTRIC INDIA PVT. LTD. Ahmedabad Branch
B/4, 3rd Floor, Safal Profitaire, Corporate Road, Prahaladnagar, Satellite, Ahmedabad, Gujarat-380015, India
Tel: +91-79-6512-0063

America

18 North America FA Center

MITSUBISHI ELECTRIC AUTOMATION, INC.
500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A.
Tel: +1-847-478-2469 / Fax: +1-847-478-2253

Mexico

19 Mexico FA Center

MITSUBISHI ELECTRIC AUTOMATION, INC. Mexico Branch
Mariano Escobedo #69, Col. Zona Industrial, Tlalnepanitla Edo, C.P.54030, Mexico
Tel: +52-55-3067-7511

Brazil

20 Brazil FA Center

MITSUBISHI ELECTRIC DO BRASIL COMÉRCIO E SERVIÇOS LTDA.
Rua Jussara, 1750-Bloco B Anexo, Jardim Santa Cecilia, CEP 06465-070, Barueri-SP, Brasil
Tel: +55-11-4689-3000 / Fax: +55-11-4689-3016

21 Brazil Boituva FA Center

MELCO CNC DO BRASIL COMÉRCIO E SERVIÇOS S.A.
Acesso Jose Sartorelli, KM 2.1 CEP 18550-000 Boituva-SP, Brasil
Tel: +55-15-3363-9900 / Fax: +55-15-3363-9911

Europe

22 Europe FA Center

MITSUBISHI ELECTRIC EUROPE B.V. Polish Branch
ul. Krakowska 50, 32-083 Balice, Poland
Tel: +48-12-630-47-00 / Fax: +48-12-630-47-01

23 Germany FA Center

MITSUBISHI ELECTRIC EUROPE B.V. German Branch
Gothaer Strasse 8, D-40880 Ratingen, Germany
Tel: +49-2102-486-0 / Fax: +49-2102-486-1120

24 UK FA Center

MITSUBISHI ELECTRIC EUROPE B.V. UK Branch
Travellers Lane, Hatfield, Hertfordshire, AL10 8XB, U.K.
Tel: +44-1707-28-8780 / Fax: +44-1707-27-8695

25 Czech Republic FA Center

MITSUBISHI ELECTRIC EUROPE B.V. Czech Branch
Avenir Business Park, Radlicka 751/113e, 158 00 Praha5, Czech Republic
Tel: +420-251-551-470 / Fax: +420-251-551-471

26 Russia FA Center

MITSUBISHI ELECTRIC EUROPE B.V. Russian Branch St. Petersburg office
Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benuea", office 720; 195027, St. Petersburg, Russia
Tel: +7-812-633-3497 / Fax: +7-812-633-3499

27 Turkey FA Center

MITSUBISHI ELECTRIC TURKEY A.Ş Umraniye Branch
Serifali Mahallesi Nutuk Sokak No:5, TR-34775 Umraniye, Istanbul, Turkey
Tel: +90-216-526-3990 / Fax: +90-216-526-3995

► Specifications/Products

■ Operating Environment

Item		Details	
Personal computer	OS	Microsoft® Windows® 8.1 Operating System *1 Microsoft® Windows® 8.1 Pro Operating System *1 Microsoft® Windows® 8.1 Enterprise Operating System *1 Microsoft® Windows® 8 Operating System *1 Microsoft® Windows® 8 Pro Operating System *1 Microsoft® Windows® 8 Enterprise Operating System *1 Microsoft® Windows® 7 Starter Operating System *1 Microsoft® Windows® 7 Home Premium Operating System *1 Microsoft® Windows® 7 Professional Operating System *1 Microsoft® Windows® 7 Ultimate Operating System *1	Microsoft® Windows® 7 Enterprise Operating System *1 Microsoft® Windows Vista® Home Basic Operating System Microsoft® Windows Vista® Home Premium Operating System Microsoft® Windows Vista® Business Operating System Microsoft® Windows Vista® Ultimate Operating System Microsoft® Windows Vista® Enterprise Operating System Microsoft® Windows® XP Professional, Service Pack2 or later Microsoft® Windows® XP Home Edition, Service Pack2 or later Microsoft® Windows® 2000 Professional, Service Pack4 or later
	CPU	Intel®Core™2 Duo Processor 2 GHz or more	
	Required memory	Recommended 1 GB or more	
Available hard disk capacity		When installing GX Works2: HDD available capacity is 2.5 GB or more. When operating GX Works2: Virtual memory available capacity is 512 MB or more.	
Disk drive		CD-ROM supported disk drive	
Monitor		Resolution 1024 × 768 pixels or higher	

*1 64-bit edition supported

■ Supported Programmable Controller CPU

Series name		Model
MELSEC-Q Series	Basic model	Q00JCPU, Q00CPU, Q01CPU
	High-performance model	Q02CPU, Q02HCPU, Q06HCPU, Q12HCPU, Q25HCPU
	Universal model	Q00UJCPU, Q00UCPU, Q01UCPU, Q02UCPU, Q03UDCPU, Q03UDECPU, Q04UDHCPU, Q04UDEHCPU, Q06UDHCPU, Q06UDEHCPU, Q10UDHCPU, Q10UDEHCPU, Q13UDHCPU, Q13UDEHCPU, Q20UDHCPU, Q20UDEHCPU, Q26UDHCPU, Q26UDEHCPU, Q50UDEHCPU, Q100UDEHCPU, Q03UDVCPU, Q04UDVCPU, Q06UDVCPU, Q13UDVCPU, Q26UDVCPU
	Remote I/O	QJ72LP25, QJ72BR15
	Process CPU	Q02PHCPU, Q06PHCPU, Q12PHCPU, Q25PHCPU
Redundant CPU	Q12PRHCPU, Q25PRHCPU	
LCPU	L02SCPU, L02SCPU-P, L02CPU, L02CPU-P, L06CPU, L06CPU-P, L26CPU, L26CPU-P, L26CPU-BT, L26CPU-PBT, LJ72GF15-T2, LJ72MS15	
FXCPU	FX0s, FX0, FX0N, FX1, FX1s, FX1N, FX1NC, FXU, FX2C, FX2N, FX2NC, FX3s, FX3G, FX3GC, FX3u, FX3UC	
QCPU (A mode) *2	All types	
QSCPU *2	All types	
QnACPU *2	All types	
ACPU *2	All types	
Motion controller (SCPU) *2	All types	
CNC (M6, M7) *2	All types	

*2 These modules are supported with using GX Developer.

■ Product Information

Type	Model	Outline
MELSOFT iQ Works	SW2DND-IQWK-E	FA engineering software*3 • System Management Software: MELSOFT Navigator • Controller Programming Software: MELSOFT GX Works3, GX Works2, GX Developer • Motion Programming Software: MELSOFT MT Works2 • HMI Programming Software: MELSOFT GT Works3 • Robot Programming Software: MELSOFT RT ToolBox2 mini • Inverter Setup Software: MELSOFT FR Configurator2 • MITSUBISHI ELECTRIC FA Library
MELSOFT GX Works3	SW1DND-GXW3-E	Controller Programming Software: MELSOFT GX Works3 MITSUBISHI ELECTRIC FA Library Comes with GX Works2 and GX Developer
MELSOFT GX Works2	SW1DNC-GXW2-E	Controller Programming Software Comes with GX Developer

*3 For detailed information about supported modules, refer to the manuals of the relevant software package.

■ Related Software Products

Type	Model	Outline
PX Developer	SW1D5C-FBDQ-E	FBD software package for process control
	SW1DNC-FBDQMON-E	Process control FBD software package monitoring tool
GX Developer	SW8D5C-GPPW-E	MELSEC programmable controller programming software
	SW8D5C-GPPW-EV	MELSEC programmable controller programming software (upgrade)

[Available for free*4]

Type	Model	Outline
GX LogViewer	SW1DNN-VIEWER-E	Logging data display and analysis tool

*4 To receive a copy of GX LogViewer, contact your local Mitsubishi Electric representative.

■ Manuals

[Operating manual *5]

Manual name	Supply status	IB/SH No.
GX Works2 Version 1 Operating Manual (Common) Explains the system configuration of GX Works2 and the functions common to Simple project and Structured project such as parameter setting, operation method for the online function.	Sold separately	SH-080779ENG
GX Works2 Version 1 Operating Manual (Simple Project) Explains methods for such as creating and monitoring programs in Simple project of GX Works2.	Sold separately	SH-080780ENG
GX Works2 Version 1 Operating Manual (Simple Project, Function Block) Explains methods for such as creating function blocks, pasting function blocks to sequence programs, and operating FB library in Simple project of GX Works2.	Sold separately	SH-080984ENG
GX Works2 Version 1 Operating Manual (Structured Project) Explains methods for such as creating and monitoring programs in Structured project of GX Works2.	Sold separately	SH-080781ENG
GX Works2 Version 1 Operating Manual (Intelligent Function Module) Explains methods of intelligent function module for such as parameter setting, monitoring programs, and predefined protocol support function in GX Works2.	Sold separately	SH-080921ENG
GX Works2 Beginner's Manual (Simple Project) Explains fundamental methods for such as creating, editing, and monitoring programs in Simple project for users inexperienced with GX Works2.	Sold separately	SH-080787ENG
GX Works2 Beginner's Manual (Structured Project) Explains fundamental methods for such as creating, editing, and monitoring programs in Structured project for users inexperienced with GX Works2.	Sold separately	SH-080788ENG

*5 The operating manuals are included on the CD-ROM with the software package.
Manuals in printed form are sold separately for single purchase.
Order a manual by quoting the manual number (model code) listed in the upper table.

► FA Products

PLC

MELSEC-Q Series Universal Model

Introducing the high-speed QCPU (QnUDVCP) for faster processing of large data volumes.

- ◎Realize high-speed, high-accuracy machine control with various iQ Platform compatible controllers and multiple CPUs.
- ◎Easily connect to GOTs and Programming tools using built-in Ethernet port.
- ◎25 models from 10K steps small capacity to 1000K steps large capacity, are available.
- ◎Seamless communication and flexible integration at any network level.



Product Specifications

Program capacity	10K steps to 1000K steps
Number of I/O points [X/Y], number of I/O device points [X/Y]	256 points to 4096 points/8192 points
Basic instruction processing speed (LD instruction)	120 ns to 1.9 ns
External connection interface	USB (all models equipped), Ethernet, RS-232, memory card, extended SRAM cassette
Function module	I/O, analog, high-speed counter, positioning, simple motion, temperature input, temperature control, network module
Module extension style	Building block type
Network	Ethernet, CC-Link IE controller network, CC-Link IE field network, CC-Link, CC-Link/LT, MELSECNET/H, SSCNETIII (/H), AnyWire, RS-232, RS-422

PLC

MELSEC-L Series

“Light & Flexible” condensing various functions easily and flexibly.

- ◎CPU equipped as a standard with various functions including counter, positioning and CC-Link.
- ◎The base-less structure with high degree of freedom saves space in the control panel.
- ◎Easily confirm the system status and change the settings with the display unit.
- ◎Ten models are available in program capacities from 20 k steps to 260 k steps.



Product specifications

Program capacity	20 k steps/60 k steps/260 k steps
Number of input/output points [X/Y]	1024 points/4096 points
Number of input/output device points [X/Y]	8192 points
Basic instruction processing speed (LD instruction)	60 ns/ 40 ns/ 9.5 ns
External connection interface	USB, Ethernet, RS-232, SD memory card, CC-Link (L26CPU-BT/PBT)
Function modules	I/O, analog, high-speed counter, positioning, simple motion, temperature control, network module
Unit expansion style	Base-less structure
Network	Ethernet, CC-Link IE Field network, CC-Link, CC-Link/LT, SSCNETIII(/H), RS-232, RS-422

HMI

Graphic Operation Terminal GOT2000 Series GT27 Model

To the top of HMIs with further user-friendly, satisfactory standard features.

- ◎Comfortable screen operation even if high-load processing (e.g. logging, device data transfer) is running. (Monitoring performance is twice faster than GT16)
- ◎Actual usable space without using a SD card is expanded to 128MB for more flexible screen design.
- ◎Multi-touch features, two-point press, and scroll operations for more user-friendliness.
- ◎Outline font and PNG images for clear, beautiful screen display.



Product Specifications

Screen size	15", 12.1", 10.4", 8.4"
Resolution	XGA, SVGA, VGA
Intensity adjustment	32-step adjustment
Touch panel type	Analog resistive film
Built-in interface	RS-232, RS-422/485, Ethernet, USB, SD card
Applicable software	GT Works3
Input power supply voltage	100 to 240VAC (+10%, -15%), 24VDC (+25%, -20%)



Inverter

FR-A800 Series



High-functionality, high-performance inverter

- ◎Realize even higher responsiveness during real sensor-less vector control or vector control, and achieve faster operating frequencies.
- ◎The latest automatic tuning function supports various induction motors and also sensor-less PM motors.
- ◎The standard model is compatible with EU Safety Standards STO (PLd, SIL2). Add options to support higher level safety standards.
- ◎Control and monitor inverters via CC-Link/CC-Link IE Field Network (option interface).

Product Specifications

Inverter capacity	200V class: 0.4kW to 90kW, 400V class: 0.4kW to 500kW
Control method	High-carrier frequency PWM control (Select from V/F, advanced magnetic flux vector, real sensorless vector or PM sensorless vector control), vector control (when using options)
Output frequency range	0.2 to 590Hz (upper limit is 400Hz when using advanced magnetic flux vector control, real sensorless vector control, vector control or PM sensorless vector control)
Regenerative braking torque (Maximum allowable duty)	200V class: 0.4K to 1.5K (150% at 3%ED) 2.2K/3.7K (100% at 3%ED) 5.5K/7.5K (100% at 2%ED) 11K to 55K (20% continuous) 75K or more (10% continuous), 400V class: 0.4K to 7.5K (100% at 2%ED) 11K to 55K (20% continuous) 75K or more (10% continuous)
Starting torque	200% 0.3Hz (3.7K or less), 150% 0.3Hz (5.5K or more) (when using real sensorless vector, vector control)

Sensor-less Servo

FR-E700EX Series, MM-GKR Series



Compact and high-function drive unit, low-inertial small capacity sensor-less PM motor

- ◎Use PM sensor-less vector control to control dedicated PM motors with high accuracy without an encoder.
- ◎High-accuracy speed control (speed fluctuation rate $\pm 0.05\%$) and positioning control are supported.
- ◎The dedicated PM motor (MM-GKR) is quiet as it has no cooling fan. The compact and lightweight unit also supports reduction gears.
- ◎The standard model supports RS-485 communication. CC-Link communication is supported with an additional option.

Product Specifications

Drive unit / motor capacity	200V class: 0.1kW to 0.75kW
Control method	PM sensor-less vector control (low speed range: high frequency superimposition control)
Rated speed	3000r/min
Speed fluctuation rate	$\pm 0.05\%$ (at 0 to 100% load fluctuation)
Position control	The point table method and zero point return enable position control with absolute position commands
Command input method	
Positioning accuracy	$\pm 1.8^\circ$ (machine angle: equivalent to 200 [pulses/rev] resolution, input voltage 200V, wiring length within 5m)
Starting torque	200% (default value)
Communication specifications	Built-in: RS-485 communication (Mitsubishi inverter protocol, Modbus-RTU protocol), option: CC-Link communication

AC Servo

Mitsubishi General-Purpose AC Servo MELSERVO-J4 Series



Industry-leading level of high performance servo

- ◎Industry-leading level of basic performance: Speed frequency response (2.5kHz), 4,000,000 (4,194,304p/rev) encoder
- ◎Advanced one-touch tuning function achieves the one-touch adjustment of advanced vibration suppression control II, etc.
- ◎Equipped with large capacity drive recorder and machine diagnosis function for easy maintenance.
- ◎2-axis and 3-axis servo amplifiers are available for energy-conservative, space-saving, and low-cost machines.

Product Specifications

Power supply specifications	1-phase/3-phase 200V AC, 1-phase 100V AC, 3-phase 400V AC
Command interface	SSCNET III/H, SSCNET III (compatible in J3 compatibility mode), CC-Link IE Field Network interface with Motion, pulse train, analog
Control mode	Position/Speed/Torque/Positioning function/Fully closed loop
Speed frequency response	2.5kHz
Tuning function	Advanced one-touch tuning, advanced vibration suppression control II, robust filter, etc.
Functional safety	Conforms to functions of IEC/EN 61800-5-2, STO: Category 3 PL d, SIL 2 Conforms to Category 4 PL e, SIL 3 by a combination with MR-D30 functional safety unit
Compatible servo motor	Rotary servo motor (rated output: 0.05 to 55kW), linear servo motor (continuous thrust 50 to 3000N), direct drive motor (rated torque: 2 to 240N·m)



Exceed your expectations.

- ◎10A frame model is over 16% smaller with a width of just 36mm!!
- ◎New integrated terminal covers.
- ◎Reduce your coil inventory by up to 50%.
- ◎Be certified to the highest international levels while work is ongoing to gain other country.

Product specifications

Frame	10 A to 32 A
Applicable standards	Certification to various standards including IEC, JIS, CE, UL, TÜV, CCC.
Terminal cover	Standard terminal cover improves safety, simplifies ordering, and reduces inventory, etc.
Improved wiring	Wiring and operability are improved with streamlining wiring terminal BC specifications.
Operation coil rating	Wide range of operation coil ratings reduces number of coil types from 14 (N Series) to 7 types and simplifies selection.
Option units	Diverse lineup includes Auxiliary Contact Block, Operation Coil Surge Absorber Unit, Mechanical Interlock Unit.



High speed, high precision and high reliability industrial robot

- ◎Compact body and slim arm design, allowing operating area to be expanded and load capacity increased.
- ◎The fastest in its class using high performance motors and unique driver control technology.
- ◎Improved flexibility for robot layout design considerations.
- ◎Optimal motor control tuning set automatically based on operating position, posture, and load conditions.

Product Specifications

Degrees of freedom	Vertical:6 Horizontal:4
Installation	Vertical:Floor-mount, ceiling mount, wall mount (Range of motion for J1 is limited) Horizontal:Floor-mount
Maximum load capacity	Vertical:2-20kg Horizontal:3-20kg
Maximum reach radius	Vertical:504-1503mm Horizontal:350-1,000mm



iQ Platform compatible CNC to provide TCO reduction effect.

- ◎A CNC structured in building block method on iQ Platform.
- ◎High performance CNC integrated with high-speed PLC offers high-speed control to reduce cycle time.
- ◎A wide variety of FA products helps construct flexible lines.

Product specifications

Maximum number of control axes (NC axis + spindle + PLC axis)	16 axes
Maximum number of part system	Machining center system: 7 systems, Lathe system: 3 systems
Maximum number of NC axes per part system	8 axes
Maximum program capacity	2,000 KB (5,120 m)
Maximum number of files to store	124 files/252 files
Number of input/output points	4,096 points
Safety observation function	Safety signal comparison function, speed monitoring function, duplexed emergency stop

Microsoft, Windows, Windows Vista, Excel are registered trademarks of Microsoft Corporation in the United States and other countries. Ethernet is a trademark of Xerox Corporation. All other company names and product names used in this document are trademarks or registered trademarks of their respective companies.

Precautions before use

This publication explains the typical features and functions of the products herein and does not provide restrictions and other information related to usage and module combinations. Before using the products, always read the product user manuals. Mitsubishi Electric will not be held liable for damage caused by factors found not to be the cause of Mitsubishi Electric; opportunity loss or lost profits caused by faults in Mitsubishi Electric products; damage, secondary damage, or accident compensation, whether foreseeable or not, caused by special factors; damage to products other than Mitsubishi Electric products; and to other duties.

For safe use

- To use the products given in this publication properly, always read the relevant manuals before use.
- The products have been manufactured as general-purpose parts for general industries, and have not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the products for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- The products have been manufactured under strict quality control. However, when installing the products where major accidents or losses could occur if the products fail, install appropriate backup or fail-safe functions in the system.

Country/Region	Sales office	Tel/Fax
USA	MITSUBISHI ELECTRIC AUTOMATION, INC. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A.	Tel : +1-847-478-2100 Fax : +1-847-478-2253
Mexico	MITSUBISHI ELECTRIC AUTOMATION, INC. Mexico Branch Mariano Escobedo #69, Col. Zona Industrial, Tlalnepantla Edo, C.P.54030, Mexico	Tel : +52-55-3067-7500
Brazil	MITSUBISHI ELECTRIC DO BRASIL COMÉRCIO E SERVIÇOS LTDA. Rua Jussara, 1750-Bloco B Anexo, Jardim Santa Cecilia, CEP 06465-070, Barueri-SP, Brasil	Tel : +55-11-4689-3000 Fax : +55-11-4689-3016
Germany	MITSUBISHI ELECTRIC EUROPE B.V. German Branch Gothaer Strasse 8, D-40880 Ratingen, Germany	Tel : +49-2102-486-0 Fax : +49-2102-486-1120
UK	MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire, AL10 8XB, U.K.	Tel : +44-1707-28-8780 Fax : +44-1707-27-8695
Ireland	MITSUBISHI ELECTRIC EUROPE B.V. Irish Branch Westgate Business Park, Ballymount, IRL-Dublin 24, Ireland	Tel : +353-1-4198800 Fax : +353-1-4198890
Italy	MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Centro Direzionale Colleoni-Palazzo Sirio Viale Colleoni 7, 20864 Agrate Brianza(Milano) Italy	Tel : +39-039-60531 Fax : +39-039-6053-312
Spain	MITSUBISHI ELECTRIC EUROPE, B.V. Spanish Branch Carretera de Rubí, 76-80-Apdo. 420, 08173 Sant Cugat del Vallés (Barcelona), Spain	Tel : +34-935-65-3131 Fax : +34-935-89-1579
France	MITSUBISHI ELECTRIC EUROPE B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France	Tel : +33-1-55-68-55-68 Fax : +33-1-55-68-57-57
Czech Republic	MITSUBISHI ELECTRIC EUROPE B.V. Czech Branch Avenir Business Park, Radlicka 751/113e, 158 00 Praha5, Czech Republic	Tel : +420-251-551-470 Fax : +420-251-551-471
Poland	MITSUBISHI ELECTRIC EUROPE B.V. Polish Branch ul. Krakowska 50, 32-083 Balice, Poland	Tel : +48-12-630-47-00 Fax : +48-12-630-47-01
Sweden	MITSUBISHI ELECTRIC EUROPE B.V. (Scandinavia) Fjellievägen 8, SE-22736 Lund, Sweden	Tel : +46-8-625-10-00 Fax : +46-46-39-70-18
Russia	MITSUBISHI ELECTRIC EUROPE B.V. Russian Branch St. Petersburg office Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; RU-195027 St. Petersburg, Russia	Tel : +7-812-633-3497 Fax : +7-812-633-3499
Turkey	MITSUBISHI ELECTRIC TURKEY A.Ş Ümraniye Branch Serifali Mahallesi Nutuk Sokak No:5, TR-34775 Umraniye, Istanbul, Turkey	Tel : +90-216-526-3990 Fax : +90 -216-526-3995
Dubai	MITSUBISHI ELECTRIC EUROPE B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E.	Tel : +971-4-3724716 Fax : +971-4-3724721
South Africa	ADROIT TECHNOLOGIES 20 Waterford Office Park, 189 Witkoppen Road, Fourways, Johannesburg, South Africa	Tel : +27-11-658-8100 Fax : +27-11-658-8101
China	MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. No.1386 Hongqiao Road, Mitsubishi Electric Automation Center, Shanghai, China	Tel : +86-21-2322-3030 Fax : +86-21-2322-3000
Taiwan	SETSUYO ENTERPRISE CO., LTD. 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan, R.O.C.	Tel : +886-2-2299-2499 Fax : +886-2-2299-2509
Korea	MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. 7F-9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 157-801, Korea	Tel : +82-2-3660-9530 Fax : +82-2-3664-8372
Singapore	MITSUBISHI ELECTRIC ASIA PTE. LTD. 307, Alexandra Road, Mitsubishi Electric Building, Singapore 159943	Tel : +65-6473-2308 Fax : +65-6476-7439
Thailand	MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD. 12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpan, Khet Yannawa, Bangkok 10120, Thailand	Tel : +66-2682-6522 Fax : +66-2682-6020
Vietnam	MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED Hanoi Branch 6-Floor, Detech Tower, 8 Ton That Thuyet Street, My Dinh 2 Ward, Nam Tu Liem District, Hanoi, Vietnam	Tel : +84-4-3937-8075 Fax : +84-4-3937-8076
Indonesia	PT. MITSUBISHI ELECTRIC INDONESIA Gedung Jaya 11th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia	Tel : +62-21-3192-6461 Fax : +62-21-3192-3942
India	MITSUBISHI ELECTRIC INDIA PVT. LTD. Pune Branch Emerald House, EL-3, J Block, M.I.D.C Bhosari, Pune-411026, Maharashtra, India	Tel : +91-20-2710-2000 Fax : +91-20-2710-2100
Australia	MITSUBISHI ELECTRIC AUSTRALIA PTY. LTD. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia	Tel : +61-2-9684-7777 Fax : +61-2-9684-7245

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN

Mitsubishi Electric Corporation Nagoya Works is a factory certified for ISO14001 (standards for environmental management systems) and ISO9001(standards for quality assurance management systems)

